

# ENCM 509 - Laboratory #4

Kyle Derby MacInnis

October 14, 2015

## Abstract

This laboratory focuses on feature extraction of fingerprint ridges to help locate minutiae.

## Introduction

This lab looked at feature extraction as it applied to fingerprint analysis. This lab is part of a larger number of future labs that will use the extracted data.

## Procedure

1. Load in BMP image and convert to grayscale (intensity) image.
2. Run Lab4Fingerprint1.m and look at demonstration of feature extraction.




Figure 1: Feature Extraction used to find minutiae

3. Modify Lab4Fingerprint1.m and have it perform Histogram Equalization, and Denoising.

```
%% Exercise - Histogram Equalization
figure(101);
subplot(1,3,1);
imhist(img);
xlabel('Original Image Histogram');
% Regular Histogram Eq.
Himg = histeq(img);
subplot(1,3,2);
imhist(Himg);
xlabel('Regular Histogram Equalization');
% Adaptive Histogram Eq.
aHimg = adapthisteq(img);
subplot(1,3,3);
imhist(aHimg);
xlabel('Adaptive Histogram Equalization');
```





Figure 2: Histograms and Images for Histogram Equalization Enhancement

```

%% Exercise – Denoising Filters
% Image Adjust
Aimg = imadjust(img);
Mimg = medfilt2(img);
Wimg = wiener2(img);

figure(102);
subplot(1,3,1), imagesc(Aimg), colormap gray, title('ImageAdjust Image');
subplot(1,3,2), imagesc(Mimg), colormap gray, title('Median Filter Image');
subplot(1,3,3), imagesc(Wimg), colormap gray, title('Weiner Filter Image');

```



4. Inspect each part of the process and modify parameters to observe variation to the extracted minutiae and finished feature extractions.




Figure 3: Various Steps used in feature extraction.

5. Perform Gabor Filtering and examine parameter changes.

```
% Exercise Gabor Filtering
% Gabor Filter Parameters
x = 48; y = 32;
```

```

tx = 4; ty = 5;
angle = pi/4;
f = 0.10;
p = 36;
for i = 1:p
    angle = (pi/(p*(log(p)/log(i))))*(i);
    GabFlt = GaborFilter(x, y, tx, ty, angle, f);
    if i == 1
        Gabimg = (1/(p))*imfilter(img, GabFlt);
    elseif i > 1
        Gabimg = Gabimg + (1/p)*imfilter(img, GabFlt);
    end
    figure(104);
    imshow(Gabimg); colormap(gray);
end

```




Figure 4: Gabor Filter and Filtered Image

## Discussion

- Histogram Equalization appeared to slightly increase contrast using the *adaptive* method, but using the regular method, contrast resolution did not improve and rather most of the image contrast was reduced.
- Denoising did not have much of an effect on any of the fingerprints I had collected. It had no noticeable effects.
- By varying the parameters of the segmentation function, the borders and the *smoothness* of the enclosed border was changed. Smaller values for results in a more jittery and sharp shape, whereas larger values produced more blob-like shapes and had smooth borders.
- There were three singularity points found in my finger print. However, there was five when I used the Gabor filtered image instead.
- Reducing the size of the parameters used in the Gabor filtering for the skeleton creation resulted in a generally *stronger* skeleton whereas larger values resulted in more convoluted skeletons.

## Remarks on the Lab

This lab was quite easy to finish, and look forward to next lab.

# Appendix A: MATLAB Code

## Modified\_Lab4Fingerprint1.m

```
%===== ENCM 509 =====%
%===== Lab 4: Fingerprint: Part II =====%
%===== Fingerprint matching score =====%
% by S. Yanushkevich, February 04,2009
% updated October 1, 2014

clear all
close all

disp('-----');
disp('          Fingerprint preprocessing and feature extraction');
disp('          Biometric Technologies Laboratory, UofC');
disp('-----');

%The image acquired using an optical fingerprint sensor is a gray-scale image saved in a
%  bitmap or other image format file
%Traditionally, processing of a gray-scale fingerprint images include segmentation,
%  ridge orientation estimation,
%  a centre-of-mass or singularity point detection, ridge frequency estimation, Gabor
%  filtering,
%thinning and skeleton cleaning, and, finally, minutiae detection

%-----
%----- Reading image from a bitmap or other format
%-----

disp('Reading the image from a file')
[namefile,pathname]=uigetfile({'*.bmp;*.tif;*.tiff;*.jpg;*.jpeg;*.gif','IMAGE
Files (*.bmp;*.tif;*.tiff;*.jpg;*.jpeg;*.gif)'});
[img,map]=imread(strcat(pathname,namefile));
img=rgb2gray(img);

%% ADD FILTERING SUCH AS
%% img1 = imadjust(img); img2 = medfilt2(img);
%%

%% Exercise - Histogram Equalization

    figure(101);
    subplot(1,3,1);
    imhist(img);
    xlabel('Original Image Histogram');
    % Regular Histogram Eq.
    Himg = histeq(img);
    subplot(1,3,2);
    imhist(Himg);
    xlabel('Regular Histogram Equalization');
    % Adaptive Histogram Eq.
    aHimg = adapthisteq(img);
    subplot(1,3,3);
    imhist(aHimg);
    xlabel('Adaptive Histogram Equalization');

%% Exercise - Denoising Filters
    % Image Adjust
    Aimg = imadjust(img);
    Mimg = medfilt2(img);
    Wimg = wiener2(img);

    figure(102);
    subplot(1,3,1), imagesc(Aimg), colormap gray, title('ImageAdjust Image');
    subplot(1,3,2), imagesc(Mimg), colormap gray, title('Median Filter Image');
    subplot(1,3,3), imagesc(Wimg), colormap gray, title('Weiner Filter Image');

%% Exercise Gabor Filtering
    % Gabor Filter Parameters
    x = 48; y = 32;
    tx = 4; ty = 5;
    angle = pi/4;
```

```

f = 0.10;
p = 36;
for i = 1:p
    angle = (pi/(p*(log(p)/log(i))))*(i);
    GabFlt = GaborFilter(x, y, tx, ty, angle, f);
    if i == 1
        Gabimg = (1/(p))*imfilter(img, GabFlt);
    elseif i > 1
        Gabimg = Gabimg + (1/p)*imfilter(img, GabFlt);
    end
    figure(104);
    imshow(Gabimg); colormap(gray);
end

figure(103);
subplot(1,3,1), imshow(img), colormap gray, title('Original');
subplot(1,3,2), imshow(GabFlt), colormap gray, title('Filter');
subplot(1,3,3), imshow(Gabimg), colormap gray, title('Filtered Image');

Fp.imOrig = img;

figure(1), subplot(1,3,1), imagesc(Fp.imOrig), colormap gray, title('Original
Image');
subplot(1,3,2), imagesc(aHimg), colormap gray, title('Adaptive Hist. Eq. Image');
;
subplot(1,3,3), imagesc(Himg), colormap gray, title('Regular Hist. Eq. Image');
%% TO ADD FIGURE COMPARING FILTERS, USE
%% figure(1),
%% subplot 221, imshow(img); title('Original Image');
%% subplot 222, imshow(img1); title('imadjust');
%% subplot 223, imshow(img2); title('medfilt2');

disp('(Press any key to continue)');
pause;
% _____
%      Preprocessing: segmentation and countour
% _____

disp('Preprocessing: extracting fingerprint from background')
Fp = segmentimage(Fp);

figure(2),
subplot(1,2,1), imagesc(Fp.imSegmented), colormap gray, title('fingerprint
segmented');
subplot(1,2,2), imagesc(Fp.imContour), colormap gray, title('fingerprint
contour');

[x,y]= find(Fp.imContour);
figure(3), title('Contour'), hold on, imagesc(Fp.imOrig), colormap gray;
plot(y,x, '.'), axis ij, axis([1 size(Fp.imOrig,1) 1 size(Fp.imOrig,2)]);
hold off;

disp('(Press any key to continue)');
pause;
% _____
%      Orientation field
% _____

disp('Compute orientation field');
Fp = computeorientationarray(Fp);
figure(4), imagesc(Fp.orientationArray), title('Orientation field');
showorientationfield(Fp);

disp('(Press any key to continue)');
pause;
% _____
%      Finding the singularity point (central minutiae)
% _____

disp('Extracting the singularity point');

```

```

Fp = findsingularitypoint(Fp);
[x,y]= find(Fp.singularityArray);
figure(5), hold on, imagesc(Fp.imOrig),colormap gray;
plot(y,x,'. '), axis ij, title('Singularity Point');
hold off;

disp('(Press any key to continue)');
pause;

%-----
%----- Local ridge frequency
%-----

disp('Compute local ridge frequency');
Fp = computelocalfrequency(Fp, Fp.imOrig);
figure(6), imagesc(Fp.frequencyArray), title('Local frequencies');

disp('(Press any key to continue)');
pause;

%-----
%----- Gabor Filtering
%-----

disp('Gabor filtering and enhancing skeleton structure');
Fp = GaborEnhanced(Fp);
figure(7), imagesc(Fp.imBinary), colormap gray, title('Binarized image');
% figure(8), imagesc(Fp.imSkeleton), colormap gray, title('Skeleton');

[x,y]= find(Fp.imSkeleton);
figure(8), title('Skeleton');
hold on, imagesc(Fp.imOrig), colormap gray;
plot(y,x,'r. '), axis ij;
hold off;

disp('(Press any key to continue)');
pause;

%-----
%----- Thinning and skeleton cleaning
%-----

disp('Morphological skeleton cleaning')
Fp = cleanskeleton(Fp);
% figure(10), imagesc(Fp.imSkeleton), colormap gray, title('Skeleton');

Sk=ones(size(Fp.imSkeleton,1),size(Fp.imSkeleton,2));
Sk(1:size(Fp.imSkeleton,1)-50,1:size(Fp.imSkeleton,2)-50)=Fp.imSkeleton(26:
size(Fp.imSkeleton,1)-25,26:size(Fp.imSkeleton,2)-25);
Sk = imcomplement(Sk);
[x,y]= find(Sk);
% figure(11), title('Skeleton cleaning');
figure(9), title('Skeleton cleaning');
hold on, imagesc(Fp.imOrig),colormap gray;
plot(y,x,'r. '), axis ij;
hold off;

disp('(Press any key to continue)');
pause;

%-----
%----- Finding minutiae
%-----

disp('Extracting Minutiae')
Fp = findminutia(Fp);

[x1,y1]= find(Fp.minutiaArray==1);
[x2,y2]= find(Fp.minutiaArray==2);

```

```

figure(10),
% hold on, imagesc(Fp.imSkeleton),colormap gray, title('Minutiae');
% plot(y1,x1,'or','markersize',8);
% plot(y2,x2,'sb','markersize',8), axis ij;
% legend('End of ridge', 'Bifurcation');
% hold off;
% figure(13),
hold on, imagesc(Fp.imOrig),colormap gray, title('Minutiae')
plot(y1,x1,'or','markersize',8);
plot(y2,x2,'sb','markersize',8), axis ij;
legend('End of ridge', 'Bifurcation');
hold off;

disp('(Minutiae array contains features to be used for fingerprint comparison in
Lab 5)');

```